



Viscor Wireless Control Options

Controls*			Notes
Manufacturer	Model	Viscor Option Code V99 ()	In-Fixture or External Mount
Philips Easysense	SNS102	V99 (P01)	In-Fixture
	SNS200	V99 (P02)	In-Fixture
	SNS300	V99 (P03)	In-Fixture
	SNH200	V99 (P04)	In-Fixture
Lutron Vive	FCJS-ECO	V99 (L01)	External Mount
	FCJS-010	V99 (L02)	External Mount
	FC-Sensor	V99 (L03)	External Mount
	FC-Vsensor	V99 (L04)	External Mount
	DFCSJ-OEM-RF	V99 (L05)	In-Fixture
	DFCSJ-OEM-OCC	V99 (L06)	In-Fixture
Enlighted	SU-5E-HRx-xx	V99 (E03)	External Mount
	SU-5E-xx	V99 (E04)	In-Fixture
Nedap Luxon	IoT Node	V99 (N01)	In-Fixture
	Wireless Build-In	V99 (N02)	In-Fixture
	Wireless Build-On	V99 (N03)	In-Fixture
Ideal Audacy	SCC-1000	V99 (A01)	In-Fixture
	SCL-1000	V99 (A02)	In-Fixture
	SCD-1000	V99 (A03)	External Mount
Douglas Dialog	BT-PP20-A	V99 (D01)	External Mount
	BT-FMS-A	V99 (D02)	External Mount
OSRAM Encelium	ZBHA-CLM-DIM	V99 (S01)	In-Fixture
	ZBHA-CLM-DEXAL	V99 (S02)	In-Fixture
	EN-WCM-ZB	V99 (S03)	External Mount
	EN-WALC-ZB	V99 (S04)	External Mount
	SensiLUM (58286)	V99 (S05)	In-Fixture
Casambi	CBU-ASR	V99 (C01)	In-Fixture

*Other options may be available, consult factory. Specifications and data subject to change without notice.