RVL Series Recessed Installation Instructions

| ERP: | IIS00354 |
|-------|------------|
| Date: | 08/15/2022 |

Rev 1.0

NOTES

- Installation should be completed by an individual familiar with the construction and operation of the luminaire.
- Installation of luminaire must be in accordance with nation and local building and electrical codes.
- Carefully read and follow all warnings and instructions before installing or servicing the luminaire.
- Instructions do not cover all details and all possible product configurations
- Do not restrict luminaire ventilation.
- Ensure LED luminaire is not covered with material that will prevent convection or conduction cooling.
- Do not exceed luminaire's maximum ambient temperature.
- Ensure LED luminaire has the correct polarity before installation.

These products have maximum rated output voltage that exceeds the voltage limits that cannot be accessible based on voltage restrictions for Class 2 circuits in Canadian Electrical Code. This output complies with the definition of Class 2 per Canadian Electrical Code. This product complies with this requirement since the installation instruction requires installation in restricted access area.

WARNINGS

Electric shock:

- Disconnect or turn off power before installing or servicing luminaire. Fixture should ONLY be powered on with access plate
- installed in fixture.
- All electrical wiring to be completed by a qualified licensed electrician in accordance with local and National/Canadian Electrical Code.
- Ensure supply voltage corresponds with the correct ballast/driver voltage.
- Avoid exposing wiring to metal edges and sharp objects.
- Ensure that the luminaire is properly grounded to prevent electric hazards.
- Before powering up fixture, perform appropriate testing to ensure the fixture is properly grounded


- Keep flammable and combustible materials away from the light source and/or lens.
- Use correctly rated supply conductors as indicated by product labelina.

Burn:

Fire:

- Allow luminaire to cool before handling luminaire.
- Personal Injury:
- Wear safety glasses and gloves when handling the luminaire to avoid physical injury.
- Avoid direct eye contact with light source.
- Always support the weight of the luminaire.

Manufacturer is not responsible for any injuries due to the improper installation or handling of its products.




2nd notch for 1 11/16" Main Tee

ERP: IIS00354 Date: 08/15/2022

Rev 1.0

REMOVE/INSTALL LENS




- 1. Begin at the end of the divider trim where it meets the end plate. Use flat screwdriver and gently pry back the lens and use fingers to remove.
- 2. Repeat same steps for other side.

Cleaning and Maintenance

1. Use a damp, lint-free cloth to wipe lens. Don not use solvents or cleaners containing abrasive agents. When cleaning the fixture, make sure the power is turned off, and any liquid spray should be applied to the cleaning cloth and not sprayed directly onto the fixture itself.

REMOVE/INSTALL DRIVER COMPARTMENT



- 1. Select one of the two compartment covers. Remove 2 screws to gain access to driver compartment.
- 2. Re-install cover.